



NESPRESSO MACHINE




1. Connect to electric source.
Set the water tank.
Turn on the coffee machine.
When the brewing button light stop blinking (steadg light)
the machine is ready. Raise the open / close lever and insert capsule.




2. Lower the open / close lever
Make sure the capsule insertion slot is securely closed.

*For hot water step ① ~ ② can be skipped.



3. Place the under coffee outlet.
Make sure the coffee outlet is not touching the cup.




4. Press the menu button to extract

Hot water button
Lungo button
Espresso button

<Liquid volume is based on the first setting>


Espresso	40ml
Lungo	110ml
Americano (Hot water button + Espresso button)	Coffee : 25ml Hot water : 125ml
Americano XL (Hot water button + Lungo button)	Coffee : 40ml Hot water : 160ml
Hot water	200ml



For Americano, press the hot water button and the espresso button simultaneously.
For Americano XL, press the hot water button and the Lungo button simultaneously.


AmericanoXL
Americano

The pressed button flashes during extraction.
When extraction is finished, the light turns on.
After extract, remove the cup from the cup stand.




5. Raise the open/close lever
Used capsules fall into the capsule container.

ネスプレッソ コーヒーメーカー



1. 電源に接続する。
水をセットする。
コーヒーメーカーの電源を入れる。
抽出ボタンの点滅が点灯に変わったら、抽出準備完了です。
開閉レバーを完全に上げて、ネスプレッソコーヒーカプセルを入れる。




2. 開閉レバーを下げる
カプセル挿入口が確実に閉じていることを確認してください。

※給湯のみの場合、手順①～②は不要です。



3. カップを置く。
コーヒー抽出口がカップに触れていないことを確認してください。




4. メニューボタンを押して抽出します

お湯ボタン
ルンゴボタン
エスプレッソボタン

抽出量(初期設定値)


エスプレッソ	約40ml
ルンゴ	約110ml
アメリカーノ (お湯ボタン+ エスプレッソボタン)	コーヒー:約25ml お湯:約125ml
アメリカーノXL (お湯ボタン+ ルンゴボタン)	コーヒー:約40ml お湯:約160ml
お湯	約200ml



アメリカーノの場合は、お湯ボタンとエスプレッソボタンを同時に押します。
アメリカーノXLの場合は、お湯ボタンとルンゴボタンを同時に押します。

アメリカーノXL
アメリカーノ

抽出中は押したボタンが点滅します。
抽出が終わると点灯に変わります。
抽出後、カップをカップ台からおろしてください。



5. 開閉レバーを上げる
使用済みカプセルがカプセルコンテナに落ちます。